



TELEVISION INSTRUCTIONS

Basic operation

- Power: Press the button on the remote control.
- Volume/channels: Use the arrows or numbers.
- Menu: Press the gear icon for settings.
- Subtitles: Activate via the menu.

Settings

- WiFi: Go to Network > WiFi > Select network > Password.

Connections

- HDMI: For devices such as consoles (3 ports).
- USB: Play media (photos, videos).
- Bluetooth: Pair headphones via the menu.

Smart Functions

- Apps: Netflix, YouTube, etc. via the home screen (log in with your account).